



Anschlusschema / Schéma de raccordement / Schema di allacciamento

ECOAIR EVO HT VERSION

1)



2)



230V N
50/60Hz L

a) 230V N
50/60Hz L

b) 230V N
50/60Hz L